


1/2" ANGLE AIR IMPACT WRENCH (Twin Hammer)



INDEX NO.	PARTS NO.	DESCRIPTION	Q'TY
1	RA4002TA01	C-Ring	1
2	RA4002TA02	Screw	4
3	RA4002TA03	Hammer Case	1
4	RA4002TA04	O-Ring	1
5	RA4002TA05	Bushing	1
6	RA4002TA06	Anvil Collar	1
7	RA4002TA07	O-Ring	1
8	RA4002TA08	Anvil	1
9	RA4002TA09	Hammer Pin	2
10	RA4002TA10	Hammer Cage	1
11	RA4002TA11	Hammer Dog	2
12	RA4002TA12A	Front Gasket	1
13	RA4002TA13	Motor Housing	1
14	RA4002TA14	Muffler	1
15	RA4002TA15	O-Ring	2
16	RA4002TA16	O-Ring	1
17	RA4002TA17	Ball Bearing	1
18	RA4002TA18	Front Plate	1
19	RA4002TA19	Front Plate Washer	1
20	RA4002TA20	Cylinder	1
21	RA4002TA21	Spring Pin	1
22	RA4002TA22	Rotor	1
23	RA4002TA23	Rotor Blade	8
24	RA4002TA24	Rear Plate Washer	1
25	RA4002TA25	Rear Plate	1
26	RA4002TA26	Ball Bearing	1
27	RA4002TA27	Reverse Valve	1
28	RA4002TA28	O-Ring	1
29	RA4002TA29A	Rear Gasket	1
30	RA4002TA30	Rear Cover	1
31	RA4002TA31	Screw	4
32	RA4002TA32	Steel Ball	1

INDEX NO.	PARTS NO.	DESCRIPTION	Q'TY
33	RA4002TA33	Spring	1
34	RA4002TA34	Screw	1
35	RA4002TA35	Reverse Lever	1
36	RA4002TA36	Spring Pin	1
37	RA4002TA37	Trigger	1
38	RA4002TA38	Pin	1
39	RA4002TA39	O-Ring	1
40	RA4002TA40	Set Screw	1
41	RA4002TA41	Shaft	1
42	RA4002TA42	O-Ring	1
43	RA4002TA43	O-Ring	1
44	RA4002TA44	Set Screw	
45	RA4002TA45	Turn Base	
46	RA4002TA46	Set Screw	
47	RA4002TA47	O-Ring	
48	RA4002TA50	O-Ring	1
49	RA4002TA51	Joint tube	
50	RA4002TA48	Washer	1
51	RA4002TA49	Lock nut	1
52	RA4002TA52	Handle Grip	1
53	RA4002TA53	Washer	1
54	RA4002TA54	Spring	1
55	RA4002TA55	Washer	1
56	RA4002TA56	Nut	1
57	RA4002TA57	Retainer	1
58	RA4002TA58	Valve Stem	1
59	RA4002TA59	Spring	1
60	RA4002TA60	O-Ring	1
61	RA4002TA61	Hose Adaptor -18NPT	1
62		Hose Adaptor -19PT	
63		Hose Adaptor -19PF(BSP)	
64	RA4002TA62	Washer	1

Consumable parts No. 4, 6, 12, 23, 28, 29, 42, 43, 45, 48, 59

HIW-A04500T