


FLEX HEAD RUST REMOVAL



PARTS LIST

NO	PARTS NO	DESCRIPTION	Q'TY
1	ST15401AS	REGULATOR SET	1
2	OB-30	SNAP RING	1
3	OBS05AS	VALVE STEM SET	1
4	ST15407	AIR INLET	1
5	ST29008-1AS	EXHAUST SLEEVE	1
6	ST29043	MUFFLER	1
7	ST288315AS	VALVE SET	1
8	ST29014-2	PROTECTING RUBBER	1
9	ST29015	HOUSING	1
10	ST200A13	SAFETY THROTTLE	1
11	12012.1	SPRING PIN	1
12	22536A	BEARING (626ZZ)	1
13	ST15419B	REAR PLATE	1
14	ST29020	ROTOR BLADE	4
15	ST25723	ROTOR	1
16	ST29022AAS	CYLINDER SET	1
17	ST29725	FRONT PLATE	1
18	21024	BEARING (608ZZ)	1
19	50310	WASHER	1
20	OB-31	BEARING (6001Z)	1
21	ST28027	GEAR LINK	1
22	ST165029AS	GEAR SET	3
23	ST29213623	GEAR PLATE	1

HMSR-292136

DEC. 2023

NO	PARTS NO	DESCRIPTION	Q'TY
24	ST87029	BEARING (6201ZZ)	1
25	ST29213625	COUPLING NUT	1
26	ST29213626	CLAMP NUT	1
27	ST29213627	HANDLE LINK	1
28	ST29213628	WASHER	1
29	ST29213635	POWER SHAFT	1
30	ST292131	STEEL BALL (1/4")	2
31	ST292132A	SCREW (M5*8L)	2
32	ST292133	SOCKET JOINT	1
33	ST29213633AS	DRIVE SHAFT SET	1
34	ST29213641AS	FLEX SHAFT SET	1
35	ST292134	CLAMP NUT	1
36	ST292142	STEEL RING	1
37	ST292143AS	LOCK RING SET	1
38	ST292144	RETAINER RING	1
39	ST29213639	GUARD	1
40	ST81647	SCREW (M4*12L)	1
41	ST21538	NUT	1
42	BT246659.1	SCREW (M6*25L)	1
43	BT292129	STOP SPANNER	1
44	60929	HEX (5MM)	1
45	BT29213645	HANDLE	1

Consumable parts No. 7, 12, 14, 15, 18, 21, 22, 24, 34